

Zenius and Primacy ID Card Printers

The Zenius and Primacy ID Card Printers can help organizations who use integrated ID cards with their check-in systems. You can design these card with barcodes to scan and check people in using the [eMedia - Cards CS software](#) that comes with the printer.

✔ These ID Card printers work with the following software products: ACS desktop and OnDemand (Windows environment only), and HeadMaster desktop and OnDemand (Windows environment only).

To view forms and supplies that work with our software and services, visit our [online store](#).

Operating System Requirements

To use the Zenius Single Sided, Primacy Single Sided and Primacy Dual Sided ID card printers, you must run one of the following operating systems: Windows® 8, Windows® 7, or Windows® Vista.

Installing the Card Printer

1. Insert the CD that came with your printer. When the language prompt displays, select **English**.
2. Select the printer you are installing (**Zenius** or **Primacy**).
3. Select to **Install the driver**, and click **OK** for English.
4. Click **Next** to install the Evolis Premium Suite.
5. Accept the warranty terms of agreement, then click **Next** for the following four prompts.
6. In the Setup window, select all check boxes to install the desktop icons. Click **Next**, then click **Install**.
7. When the software installation warning displays, click **Continue Anyway**.
8. Click **Next** on the following two prompts, then click **Finish**.